

## “Dual Layer” BSD Blind Spot Detection System

Model No.: C93-US4



## User Manual & Installation Guide

## GENERAL CUSTOMER INFORMATION

Thank you for choosing to purchase our “Dual Layer” vehicle series BSD microwave blind spot detection system products. Our aim is to supply you with the best quality product with the best possible service. For the best operating performance and to avoid any false alarm or function failure, we strongly suggest reading this user manual carefully before installation and use.


### 1. List of Items

| No. | Item name                         | Quantity | Photos                                                                                |
|-----|-----------------------------------|----------|---------------------------------------------------------------------------------------|
| 1   | Main Control Unit                 | 1        |    |
| 2   | Microwave Sensor                  | 2        |    |
| 3   | BSD Main Harness                  | 1        |   |
| 4   | Ultrasonic sensor                 | 4        |  |
| 5   | Ultrasonic sensor Extension Cable | 4        |   |
| 6   | Microwave Sensor Harness          | 2        |  |
| 7   | LED Light                         | 2        |  |
| 8   | LED Light Extension Cable         | 2        |  |
| 9   | Buzzer                            | 1        |  |
| 10  | 27mm Hole saw                     | 1        |  |
| 11  | User Manual                       | 1        |  |
| 12  | Cable Tie                         | 1        |  |


## 2. Product Specifications:

| Numbering | Project                                    | Technical Parameters                                                                 |
|-----------|--------------------------------------------|--------------------------------------------------------------------------------------|
| 1         | Working Voltage                            | DC 9V ~ 36V                                                                          |
| 2         | Working Current                            | ≤ 400mA                                                                              |
| 3         | Detection Speed Range                      | 1km/h ~ 120km/h                                                                      |
| 4         | 77GHz sensor<br>Maximum Detection<br>Range | Truck: 0.3m-30m<br>Vehicle: 0.3m-30m<br>Motorcycle: 0.3m-30m<br>Pedestrian: 0.3m-10m |
| 5         | Ultrasonic sensor<br>Detection Range       | 0.2-2.0m                                                                             |
| 6         | Buzzer Alarm Mode                          | LED + Buzzer Alarm                                                                   |
| 7         | Horizontal Detection Angle                 | 120°                                                                                 |
| 8         | Working Temperature                        | -20℃ ~ +70℃                                                                          |
| 9         | Storage Temperature                        | -30℃ ~ +80℃                                                                          |
| 10        | Water Proof                                | IP67                                                                                 |
| 11        | Sensor Size                                | 87.5 x 67.5 x 49mm                                                                   |


## 3. Installation diagram:




4. Wire Connection Diagram



## 5. Installation guide:



Ultrasonic Radar .  
Ensure the installation position  
of A is aligned with that of D.  
Ensure the installation position  
of B is aligned with that of C.



Ultrasonic Radar .  
Ensure the installation position  
of A is aligned with that of D.  
Ensure the installation position  
of B is aligned with that of C.

**Installation Note:** Microwave sensor placement may vary by vehicle for optimal performance with Ultra-sonic fender sensors.

## 5.1 Millimeter Sensors Installation :



Left Millimeter Sensor (above)



Right Millimeter Sensor (above)



Measure the installation height drill holes



Drilling




Fixing screws



Installation Complete

Note the orientation of the probe installation, with the rear radar bevel facing the rear of the vehicle and the “UP” logo facing up.



The Millimeter sensor is required to be installed on the side of truck. The height range 80-120cm. 30” to 47” inches. Please note the sensors installation direction. Do not install sensors in the wrong direction, which may produce False positive Alerts.

## 5.2 Ultrasonic sensor installation:



4 Sensors



Installation height



Drilling

The ultrasonic sensors can be mounted on both sides of the vehicle (2 on each fender) above the tires. Or can have 3 on the IE: passenger front fender and 1 on the Bumper as shown) The recommended height is 60-120 cm (23” inches to 47” inches). The distance between the two probes is 40-50 cm. (15” inches to 20” inches).The detection angle of the ultrasonic probe is 60 degrees.

## 5.3 Installation Attention

5.3.1 Remove (Loosen) the Negative Line from the battery before installing.

5.3.2 When removing the connector, do not pull the harness too hard, otherwise it may damage the harness, When the connector is inserted, should be inserted until the real fastening (have a fasten voice)

5.3.3 The wiring fixed in the vehicles wiring harness with the cable ties in the package. So that it does not sag and cut off the excess part of the cable ties.

5.3.4 When disassembly and installation, please follow the requirements of the vehicle maintenance manual to avoid damaging parts. If you accidentally damaged parts, please replace the corresponding parts.

## 5.4 Microwave sensor layout requirements

5.4.1. Microwave sensor (signal emission surface) can only penetrate plastic bumper.


5.4.2. Microwave sensor (signal emission surface) can't have metal in front, of it being it will interfere with proper functioning.

5.4.3. Please do not install microwave sensor (signal emission surface) in front of fluorescent light.

5.5 Following the labels on the wires, connect the ACC, Left Turn Signal, Right Turn Signal, Reverse Light, and GND cables to their corresponding power sources in the vehicle, respectively.

5.6 Route the main harness along the left side to the cab control center, and installation the LED lights and buzzer.

5.6.1 The LED lights installed on A column left and right inside the vehicle.



5.6.2 The buzzer's installation location can be customized based on your visual preferences. The location is for reference. Other wiring can refer the installation of the overall diagram, routine installation. customized based on your visual preferences. The location is for reference.




Other wiring can refer the installation of the overall diagram, routine installation.

## 6. Function

6.1 This product is equipped with two, millimeter-wave radars and four ultrasonic sensors. Utilizing dual-technology fusion, it achieves comprehensive blind spot coverage for vehicles. Through installing 2pcs of special 77GHZ microwave sensors on the vehicle side, when the vehicle is moving, if any moving object closed to blind area (3 meters each from right and left side, 30 meters from behind) the object will be detected by system sensors. By installing four ultrasonic sensors 2 on the left and 2 on the right sides of the front fenders of the vehicle, it can effectively alarm for objects approaching within the blind spot. The LED indicators will turn on to remind the driver, in this condition. If the driver engages directions and changes lanes, the buzzer will make a bi-bi sound to remind the driver.

### 6.2 Function Introduction:



### 6.3 Alert condition:

When the system is on and functioning, the system is designed to detect the following events:

6.3.1. Blind spots while driving: objects in the blind spot areas around your vehicle - in the lanes on the left /right and directly behind the vehicle at a distance of up to 60 ft (approximately 30m).When you're driving straight and not using your turn signal, if a vehicle traveling faster than you in the adjacent lane enters your blind spot, the LED light in the corresponding rearview mirror will illuminate continuously. This light will only turn off when the vehicle leaves your blind spot. When you actively signal your turn, if a faster vehicle enters your blind spot, the LED light in the side mirror will flash and a buzzer will sound. This warning will also cease once the vehicle leaves your blind spot.

6.3.2. Blind spots while being passed /overtaken: When vehicles are approaching/overtaking your vehicle from behind. When the vehicle is driving, if the speed is greater than the target overtaking speed, the target vehicle enters the alarm range, and the LED on the corresponding side is always on until the target vehicle leaves the alarm area and the warning is canceled;


When the speed is greater than the target overtaking speed, the target vehicle enters the monitoring range, the turn signal on the corresponding side is turned on, the LED on the corresponding side flashes, and the buzzer alarms until the target vehicle leaves the alarm area and the warning is canceled

6.3.4 Same-speed alarm (blind spot hold): When the host vehicle is slightly ahead of a target vehicle that is stationary in the host vehicle's blind spot and both vehicles are traveling at the same speed, the LED warning light will illuminate continuously. This continuous warning will remain in effect until the target vehicle exits the blind spot warning area, at which point the warning will be canceled.


## **6.4 Engaging the System:**

6.4.1 When the system is turned on each time, the system starts the self-test function, the LED indicators will flashes 2 times, and the buzzer will alarm one time , then the system goes into standby operation.


6.4.2 When the vehicle is driving forward normal, If the ultrasonic sensor detects an object near the front of the vehicle, the LED will be “Green”. If the object is detected by the millimeter-wave radar, the LED will be “Red”. If both sensors are engaged, the LED will be “Yellow”. When normal driving, if there is another vehicle closing to the left or right side of the vehicle, the left or right LED light will light. No buzzer alarm.



6.4.3 When engaging the Left directional, if there is another vehicle or person closing to the left side of the vehicle, the left LED light will flash and the buzzer will alarm.



6.4.4 When turning on the Right directional, if there another vehicle closing to the Right side of the vehicle, the Right LED light and buzzer will continue to flash, and buzz.



## 7. System Debugging

### 7.1 Vehicle parts recovery

#### 7.1 1. Confirm the installation status

- (1) Before powering on, make sure the wiring and installation are normal..
- (2) Perform a special inspection of the vehicle wiring harness. Check that it has not been improperly pressed, stretched, pinched, or otherwise damaged during installation.

#### 7.1.2. Power up

- (1) Connect the battery negative terminal (-) to ensure that the vehicle function to work properly.
- (2) If an abnormal occurrence, check the harness installed whether correct.

## 7.2 Test

7.2.1. Starting the truck engine, after ACC power on, the LED lights Yellow color which installed on the left and right side on the truck A column will always engage for 2 seconds at the same time. Also the buzzer will alarm once, that means the system check has been completed. Then system will enter into the environment adaptation -



test immediately. 5-8 seconds to enter the working state.

7.2.2 Please see 6.4 **Engaging the System** to check the system is OK and 100% functional.

7.2.3 After verifying all the functions, recovery all the parts disassembled during installation on and in the vehicle, bumpers etc.

## 8. Notice:

8.1 In the following situation, the microwave sensor may not be able to detect the target object or it is difficult to detect the target object.

- The vehicle is located at the rear blind area of the adjacent lane, but the vehicle is not near.
- The vehicle travels next to your car for a long time at almost the same speed.
- The vehicle travels from the opposite side.
- Vehicles of adjacent lanes try to overtake you.
- The adjacent lanes of the vehicle are extremely wide. The detection area of the radar sensor is set to the expressway width of road.

The system alarm lights and warning sounds may not be activated or may be delayed in the following cases.

- When the vehicle is changed from two lanes outside to adjacent lanes
- When driving on steep slopes
- Through the hills or mountain vertex
- Turning radius is small (sharp turn at the crossroad)
- There is a height difference between the driving lane and the adjacent lane.

8.2 If the width of the road is narrow, which may detect two lanes of vehicles.

## 9. General Troubleshooting

| No. | Project                                      | Reason                                                                        | Solution                                                               |
|-----|----------------------------------------------|-------------------------------------------------------------------------------|------------------------------------------------------------------------|
| 1   | Not flashing                                 | The harness interface is loose or haven't connected                           | Checking all the harness and make sure all connected                   |
|     |                                              | LED damaged                                                                   | Replace the LED Lights                                                 |
| 2   | The left and right LED alarming are opposite | The left and right lights line are wrong connected with the BSD main harness. | Swap left LED line and right LED line to connect the BSD main harness. |
| 3   | The buzzer does not alarm                    | The harness interface is loose or haven't connected                           | Checking all the harness and make sure all connected                   |
|     |                                              | Buzzer LED damaged                                                            | Replace the buzzer                                                     |

## 10. Statement:

This product is only an auxiliary driver assist and lane changing solution. While in actual use, the driver must be strictly in accordance with traffic regulations. Any driving incident or accident that may occur while using this Auxiliary sensor solution. the manufacturer and or Reseller is not responsible.